

## WHITE STAINLESS COFFEE CUP 10 oz.

SSCW10

### Settings

- **Time:** 60 seconds
- **Temperature:** 375° F
- **Pressure:** Light

### Heat Press Process

- Affix the transfer to the cup using heat tape.
- Place sacrificial paper over the transfer. Place in mug press.
- After appropriate cure time, remove from press and set aside to cool. Water bath can be used for faster cooling.



### Convection Oven Process

- **Time:** 6 -7 min. | **Temperature:** 400° F | **Pressure:** Heat Shrink Sleeves
- Preheat oven to 400F for 5-6 min. before placing cup in oven.
- Place transfer paper face down on product. Slide heat shrink sleeve over top of the transfer paper. Use a heat gun to shrink the sleeve onto the cup.
- Once preheated, place shrink wrapped tumbler in oven and heat for the recommended time. When heating multiple cups at once, additional heating time may be required.
- Immerse cup in water immediately after removing from oven to cool.

**Note:** Recommendations are safe starting points and have been tested to achieve optimal results. Due to variations in equipment and conditions, small adjustments may be needed to achieve optimal results.